





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu



XX = AA, AD...



2	A 860 842 NU
3	A 860 847 NU
4	A 860 852 NU
7	A 860 853 NU
8	A 963 033 NU
10	A 860 854 NU
11a	A 860 855 XX
11b	A 860 859 XX
11c	A 860 861 XX
11d	A 860 862 XX
11e	A 860 865 XX
12	A 860 866 NU
13	A 962 880 XX
15	A 962 878 XX
16	A 963 738 NU



ARCHIMODULE


A 1508 .. A 1509 .. A 1510 .. A 1511 ..
 A 1522 .. A 1523 ..







0216 / A 866 483
 (+ A 865 612)
 Made in Germany



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar		T		°C		MAX. 80			0,5		MAX. 10			1		5			22.5		65			55		MAX. 80			22.5		65			55		MAX. 80			22.5		65	
--	----------	------------	--	----------	--	-----------	--	----------------	--	--	------------	--	----------------	--	--	----------	--	----------	--	--	-------------	--	-----------	--	--	-----------	--	----------------	--	--	-------------	--	-----------	--	--	-----------	--	----------------	--	--	-------------	--	-----------	--